

## [ X1 ELECTRIC CROSSOVER FRONT AND BACK ]



*Special note: Not to sound uppity or perhaps even snotty in any way, but the X1 (aka; The Bass Manager) we're talking about here is not for everyone. Nope. In actual fact, it really is only for those who practiced very good judgment and became joined at the hip with our Evolution subs and tower bass modules and the IWS in-wall subwoofer systems. That said, what's all the fuss here? Well, that's sort of the point. The X1 Bass Manager does pretty much what its name implies. Its deals with fuss so you don't need to. It's the bass boss, providing extensive front-panel control of all the bass frequency parameters necessary to integrate Evolution subwoofers with evolution monitors or other satellites. In other words, it keeps all things on the bottom, in line and mighty tidy.*



## [ SPECIFICATIONS ]

Crossover Frequency:	50Hz, 80Hz, 110Hz high pass, 50Hz-140Hz adjustable low-pass filter
Crossover Slopes:	12dB/octave high pass, 12dB/octave low pass
Phase:	0/180 degrees switch, 0-90 degrees variable
Input Connectors:	XLR, RCA
Output Connectors:	XLR, RCA
Dimensions:	2.125" H x 17" W x 11.5" D
Weight:	9 lbs.
Controls:	Gain, LFE Gain, Phase, LP, HP, Boundary (+/-6db), Stereo/Mono, Trigger mode

